

Honeywell HH400 기본설정



Recall Default



USB HID Interface

2, Code128



*Enable

3, Coupon Code 128



Enable



*Enable CR Suffix